

Framework



Lower left Front lower




There are a total of 8 connection prints, each of which needs to be preloaded with 12 M4 nuts.


Use 8 BHCS M4×12 to lock the sheet metal parts and connection prints

and vertical.


Lower right


Locked with 8 BHCS M4×12
(When installing foot pads at the back, you need to replace BHCS M4×12 with BHCS M4×20, and each foot pad needs 2 BHCS M4×20)






Lower back






Front










Front and top






Upper left






Upper back





Upper right







Bottom plate




The three bottom plate connectors correspond to the screw holes of the bottom sheet metal plate. The connectors are placed outside and locked outward from the inside of the sealed box with 6 SHCS M3×4.











Use 2 SHCS M3×4 to lock the wire harness opening sealing plate from the bottom inward (the wire harness opening sealing plate is placed inside the sealing box, Screws require M3 washers)











Attach the EVA to the corresponding position of the printed part, and then use BHCS M4×20 to lock and fix the foot pads


Air purifier

For the assembly video, please refer to the link: https://youtu.be/Qe2rOObDmw0


The switch does not need to be installed. Just connect the power supply 24V to the normally open state directly.




You need to press in the 4 inlaid nuts M3*5.0*H4.0 first, and then use 4 SHCS M3×6 to lock the air purifier.




First press in the 3 inlaid nuts M3*5.0*H4.0, and then lock them with SHCS M3×6












Left panel




The left acrylic panel is locked with 22 nylon rivets







Right panel









Rear panel




The rear acrylic panel is locked with 22 nylon rivets








The printed parts used on the door need to be pre-installed with nuts in advance.




Left door

First preload 14 M3 nuts and 2 cylindrical magnets, connect the door hinges with 4 ϕ 3×20 pins, and lock the door hinges with 4 SHCS M3×8.

Use 4 SHCS M3×8 and 6 SHCS M3×12 for installing acrylic door panels (refer to the picture for installation)







Right door

First preload 14 M3 nuts and 2 cylindrical magnets, connect the door hinges with 4 φ3×20 pins, and lock the door hinges with 4 SHCS M3×8.


Use 4 SHCS M3×8 and 6 SHCS M3×12 for installing acrylic door panels (refer to the picture for installation)





Humidity Thermometer Door Lock




Press in 2 inlaid nuts M3*5.0*H4.0, snap the humidity thermometer into the printed part, and lock it on the sheet metal with SHCS M3×6







Install the lock and replace the buckle on the lock with a sheet metal buckle. Use SHCS M3×6 screws.



Insert the Teflon into the printed part and tie it with a zip tie along the top sheet metal, lock the print with SHCS M3×6



On the upper left is a light bar and Teflon tube



On the upper right is another section of the light bar and the power connection cable of the air purifier.





Teflon tubes are inserted into the print to facilitate filament entry, and the light strip and air purifier wires are connected along the sheet metal to the PCB board.

Wiring diagram

Air purifier line interface

Light strip line interface





24V power connection cable


PCB board box, material rack, tool box


The PCB board box and tool box need to be pressed into the inlay nut M3*5.0*H4.0. The PCB board is locked in the box with 2 SHCS M3×6, and the PCB board box is locked with 2 SHCS M3×6 on the sheet metal. Tool box locked with 2 SHCS M3×8





Blue position embedded nut


As shown in the picture, align the 2 small print parts with the screw holes of the material rack, and use 2 SHCS M3×16 to lock them on the sheet metal.













Motor bracket

Blue hole lock 2 SHCS
M3×4, fix the motor
bracket to the sheet
metal





You can install the power supply outside or directly on the machine according to the conditions of your machine and put it into a sealed box.

Panorama



